

'Quad Cruise' Electronic Cruise & Spray Control for Kubota RTV900

Quad Cruise

Quad Cruise is a new version of the MotorCycle Setup cruise control that is designed to operate at speeds from 4 km/h. It has also been designed to provide power to any crop spray system fitted to the vehicle - either manually, or only when the cruise control is engaged, via a 10 amp power outlet that is incorporated into the wiring loom. This means that spray operation occurs only when the bike's speed is held at the appropriate set speed on the cruise control.

The cruise control can be set to a specific speed to spray a row by pressing the SET button, turned off at the end of the row with the brake pedal. The RES button can be used to set the vehicle's speed back to the previous speed. The spray system will turn on and off with the cruise control, when the spray switch is in the AUTO position.

Every effort has been made to make the cruise control waterproof. The new computer is fully sealed, as is the electric actuator. Wherever possible sealed connectors have been used on the wiring harness.

NOTE: - Speed sensing for the cruise control is sourced from the vehicles speedometer sender. Some markets do not have a speedometer fitted on some models. If the cruise control is to be fitted to the vehicle, then a Kubota speedometer kit MUST be fitted to the vehicle.

The following provides a brief description of the power consumption and component locations of the MotorCycle Setup electronic cruise and spray control.

Current draw while the cruise control is switched on, but not engaged, is approximately 0.020 amp (0.28 watts). Current draw while the cruise control is engaged is nominally 0.5 amp (6 Watts) with peak draw at 2 amp (24 Watts). By comparison, a head light bulb typically draws about 4 amps (55 Watts), and a tail light bulb (running light) draws about 0.4 amp (5 Watts).

Installed weight of the cruise control is approximately 3kg.

Refer to the line drawing on the back of this sheet to identify the component numbers in the text.

The **Computer (1)** is mounted in the front compartment, on top of the dash board storage compartment (glove box).



The **Electric Actuator or throttle servo (2)** is mounted inside the engine bay on the left side, using two bolts that mount the cooling fan shield. An **Actuator cable (3)** connects the actuator to the vehicle's throttle mechanism (see below).



The **Throttle Lever (4)** is located on the right side of the transmission and controls the vehicle's hydrostatic transmission. The new lever and other hardware bolt directly to the vehicles throttle mechanism.

The **Control Switch (5)** is mounted on the left-hand end of the dashboard, and is screwed to the top of the dash board.



The **Wiring Loom (6)** is dedicated to the vehicle. Brake sensing is sourced from the brake light switch. Power for the cruise control is also sourced from the brake light circuit. Neutral gear position sensing is sourced from the vehicle's neutral light switch. Speed signal is sourced from the vehicle's speedometer sender. Earth (ground) is sourced from the battery negative terminal. Power for the spray system is sourced from the battery positive terminal and a two pin plug is provided at the rear of the vehicle for connection to the spray. Matching plug and terminals are provided in the kit for connection to the spray unit. Any accessory drawing less than 10 amps may be connected to this outlet.

